





Bloom


by Davy Grosemans for Sywawa




Unscrew the bolts out of the pole.




material:
- 1 small round plate
- 1 base
- 1 hex key
- 2 bolts
- 1 base
- 1 pole





Turn over the base on the packaging (to protect the base from rough surfaces).




The 2 bolts go through the base and the small round plate and are fixed into the pole.




Fix the pole tightly to the plate with the hex key. *
Rock the base plate while tightening the bolts. They should be tightened multiple times (alternating).



Remove the plastic cover. Tilt the parasol upright and remove the closing strap.



Open the parasol by lifting the slider.



To move the parasol on rough surfaces we advise you to use a trolley.

Warning:

In case of heavy wind we advise you to close the parasol.
Never leave the parasol open unattended.

Maintenance:

- Clean the parasol with water, a mild washing powder and a soft hand sponge. A mild pressure hose can be used.
- Frequently rinse the pole with clear water and a soft hand sponge.
- Always use the optional protective cover when closed to extend lifetime.

* It is possible that because of technical limitations some of the paint is missing in the countersunk hole but this won't oxidate and after installation this is not visible.

